

## What's in the box?

## We provide:

	(1) BoilerScope®
	(1) 24VDC power supply
	(1) Short DIN Rail + screws
	(1) 3-foot Ethernet cable
	(1-4) adapters, depending on the number of boilers to be monitored
П	Installation Instructions

## What do you provide?

- Cable:
  - Minimum: Two-wire cable (at least 24 AWG) to connect the BoilerScope® to a boiler and the boilers to one another.
  - Ideal (especially in areas with electrical noise): Cable with at least one twisted pair. Cat5 cable works just fine. There are more than enough wires, but the cable may be handy.
- · Small Phillips and flat-head screwdrivers.
- · Wire strippers.
- A boiler or two...

